



MAIN APPLICATIONS

Eraclene MR 80 U BCA is specifically designed for houseware and thin-walled containers. Eraclene MR 80 U shows a good balance between processability and mechanical properties.

PROCESSING NOTES

Eraclene MR 80 U BCA is readily processable by conventional injection moulding equipment with excellent results.

Typical processing conditions (*)

Temperature profile of the barrel (°C) 190 - 260

Temperature of the mould (°C) 10 - 40

(*) Processing conditions are depending on several parameters: the shape of the part to be manufactured, the localisation of the injection point, the injection moulding machine and the cooling of the mould.

STORAGE AND HANDLING

Eraclene MR 80 U BCA is supplied in pellet form. This material may readily be conveyed and bulk fed through equipment designed for conventional pelletized polyethylene resin, provided the equipment is designed to prevent accumulation of the fines and dust particles that are contained in all polyethylene resins. These fines and dust particles can, under certain conditions, pose an explosion hazard. We recommend that the conveying system used be equipped with filters of adequate size, operated and maintained in such a manner to ensure that no leaks develop and earthed adequately. We further recommend that good housekeeping should be practiced throughout your facility. The product should be stored in dry conditions at temperatures below 50°C and protected from sunlight. Improper storage can initiate degradation which results in odor generation, color changes and can have negative effects on the physical properties of the product. Before using this product, it is recommended to read and understand the relevant Safety Data Sheet.

AVAILABILITY

Contact the Versalis sales office nearest to you regarding availability and your specific application requirements.

FOOD CONTACT STATUS

Eraclene MR 80 U BCA complies with the rules and regulations of the European Union, as well as other countries, regarding the use of plastic materials in food contact applications. Certificates of compliance are available upon request.

TECHNICAL MANAGEMENT DOCUMENT 9

Central & Europe Americas

JYfgU`]g G"d"5"

<Y UOXZ Z]WY
D]U nndX f%b]
&\$ \$-G-Ubc bUA f: UbYg!≠ hU =m
hY`" '- \$&)&\$'&--, '- \$&)&\$(&&*&
hY`" '- \$&)&\$(&\$ \$) '- \$&)&\$'&\$+&
'- \$&)&\$(&-, (

AUbUcj
J]U HU`]Y f%W]SUb(h tAUB! =hU`m
hY`" \$'+*\$))&\$ *

North Europe RDW

JYfgU`]g G"d"5"

()% fciYX YgibY!g 7G &\$ \$U fXm W_)- &+ -
8ib_Yfè ifU bWY
hY`" '&, &')%* # ' ' '&, &')%&

8iYggY`XGfZ'Yf
)+\$gW\Vcfb Å 8YihgW`UbX
hY` (- %)%(\$&*\$)*%

IMPORTANT: consult the relevant safety data sheet for more detailed information. The information and data presented herein are to the best of our knowledge true and accurate but no warranty or guarantee, expressed or implied, is made nor is any liability accepted with respect to the use of such information and data. Versalis is available to provide the guaranteed values for each product on demand

DISCLAIMER: sole responsibility of the end-user to determine the safety, the regulatory compliance as well as the technical suitability of the product for the intended application. The product is not intended for use in medical devices and pharmaceutical applications; Versalis declines all responsibility and cannot be held liable in case of use in the above-mentioned applications.